

INSTALLATION & OPERATION

PCR-1830V LOAD CONTROL AND POWER CELLS FOR VARIABLE FREQUENCY AND DIRECT CURRENT POWER

POWER CELLS

Various models of the Power Cell are used to sense variable frequency and DC power. They utilize Hall effect sensors that are not affected by wave shape or frequency.

MODEL NUMBER

PH-3 For Variable Frequency Power to 350 Amps
PH-1000V For Variable Frequency Power to 1000 Amps
PH-1 For DC Power to 350 Amps
PH-1000DCV For DC Power to 1000 Amps

HOOKUP ON

Page 4
Page 4
Page 5
Page 5

These Power Cells are matched to the load with plug-in voltage and current networks.

The output of the Power Cell goes to the PCR-1830V load control.

FEATURES

3 ADJUSTABLE SET POINTS

When power reaches your selected SET POINT a built-in Relay Output is activated (tripped). Relay stays tripped (latched). You choose when to reset. The characteristics of these Set Points can be changed.

ANALOG OUTPUT

Hook to the Load Meter for monitoring load, easy setup and adjustment.

EASY SETUP WITH SET READ SWITCHES

Press the SET READ Switch and the SET POINT for that Channel is displayed on the LOAD METER.

- You **know** where the SET POINT is
- Easily verify proper operation

BUILT-IN START-UP TIMER

Adjustable Timer eliminates false trips while the Motor is starting.

FILTER OUT NUISANCE TRIPS

Adjustable On-Delay Timer. Trip won't activate until the selected delay time is exceeded. The On Delay for Set 1 can be defeated.

RESET

The Control can be Reset

- Automatically — when the overload is gone.
- Remotely — with switch, relay or programmable controller
- Manually

TRIP INHIBIT

The Control can be remotely bypassed during any part of the cycle when not required.

Also Available

Remote Set Point Adjustment

SET POINT CHARACTERISTICS

REGULAR SET POINTS

The relays trip when a Set Point is reached. Set Points can be:
High Trip — Trips when the power goes above the Set Point
Low Trip — Trips when the power goes below the Set Point
All 3 Set Points can be Regular. Set 1 can be high or low.

COMPENSATOR™ SET POINTS

For machine tool applications such as grinder gap elimination or dull tool detection the drifts in idle or "BASELINE" power should be zeroed out.

- A limit switch or programmable controller signal tells the COMPENSATOR™ each time the machine is in the idle or "BASELINE" position.
- The COMPENSATOR™ samples this power level and retains it as a reference.
- The SET POINTS are related to this BASELINE.

In other words, the COMPENSATOR™ zeroes out the BASELINE power for each cycle. The absolute trip point changes as conditions change but always remains a fixed amount away from the BASELINE. This means no constant fine tuning. It adjusts itself. Set 1 and Set 2 can be compensated.

Adjustment Ranges for Set Points

3%-50% — Expands the adjustment range to provide more sensitivity and precision at low loads (especially for COMPENSATED Set Points)

6%-100% — For General Use

On Delay — For Set 1, the Trip Delay can be removed from the circuit for maximum response speed - useful for grinder gap elimination.

CHANGING CHARACTERISTICS

The factory settings for the characteristics are marked on the Control adjacent to the Serial Number on the side. To change them, remove the cover (4 Phillips screws) and find the 6 Position DIP SWITCH.

SWITCH POSITIONS

Set 1		Set 2	
COMPENSATED	Switch 2 OFF	COMPENSATED	Switch 6 OFF
Regular	2 ON	Regular	6 ON
High Trip	3 OFF	3%-50% Range	5 ON
Low Trip	3 ON	6%-100% Range	5 OFF
3%-50% Range	1 ON		
6%-100% Range	1 OFF		
Defeat On Delay	4 OFF		

Set 3 is always Regular with 6%-100% Range.

INSTALLATION

MOUNTING

The Load Control should be mounted in a control cabinet or in a protected area. The four Phillips head screws on the Control should be removed and used for attaching the mounting brackets to the Control.

The Power Cell should be mounted so that the motor supply leads can pass through the holes. Direction is important. The Load side (the Load Controls Label) must face the load.

INPUT CONNECTIONS TO THE LOAD CONTROL


A 3 foot 4 wire shielded cable is provided to connect the Power Cell to the V Series Control. If more length is needed, use shielded cable.

White	SIG
Red	V+
Black	V-
Green	GND

Shield Wire - Connected to "Chassis GND" on Load Control NOT connected at Power Cell.

120 Volt Power

Connect to the 120VAC terminals on the Load Control. Ground the Load Control Chassis.




PH-3 & PH-1000V POWER CELLS For Three Phase Power

Pass each of the phases through the L1, L2, L3 holes in the Cell. Be certain that **DIRECTION** is correct. The LOAD side of the Cell should face the load. The Power Cell should be on the output side of the drive.

From a convenient location provide a voltage signal for each phase with 20 gauge or larger wire. The voltage signal should also come from the output side of the Drive.

- L1 to Terminal 7
- L2 to Terminal 8
- L3 to Terminal 9

Make sure that the voltage samples don't get switched



Hook up PH-1000V like PH-3

TERMINALS 1-6

- | | | |
|-------|---|-----------|
| | 1 | Chas. GND |
| Green | 2 | GND |
| Black | 3 | V- |
| Red | 4 | V+ |
| White | 5 | SIG |
- 4

PH-1 & PH-1000DCV POWER CELLS For DC Power


Pass the DC Plus or High through the L1 hole in the Cell. Be certain that **DIRECTION** is correct. The LOAD side of the Cell should face the load.

From a convenient location provide a voltage signal for each DC line with 20 gauge or larger wire.

DC Plus or High to Terminal 8
 DC Minus or Low to Terminal 9

For DC Power Measurement, Jumper Terminal 6 and 7 on the Power Cell.

For Current Measurement, remove the Jumper and remove the voltage connections to Terminal 8 and 9.



Hook up PH-1000DCV like PH-1

TERMINALS 1-6

	1	Chas. GND
Green	2	GND
Black	3	V-
Red	4	V+
White	5	SIG
5		

RESET

Control can be reset 3 ways:

- Manually with the Reset button on the Control.
- Remotely with a remotely located Reset button.
- Automatically by jumpering the Reset Terminal. The Control will then automatically reset itself when the trip condition goes away.

HOOKUP

Remote Reset —

Momentarily Connect Terminal 2 to Terminal 5 for Set 1 & Set 2
Momentarily Connect Terminal 4 to Terminal 5 for Set 3

Automatic Reset —

Jumper Terminal 2 to Terminal 5 for Set 1 & Set 2
Jumper Terminal 4 to Terminal 5 for Set 3

INHIBIT

The Control can be inhibited or bypassed with the INHIBIT. This lets you ignore the Control during certain parts of the machine cycle, if you desire.

HOOKUP

Terminal 1 to Terminal 5

BASELINE

A COMPENSATED Set point needs a zero reference. This is done 2 ways: The first way is with a limit switch or programmable controller on the machine. Usually, an existing switch or controller is used as long as it is electrically compatible. The BASELINE signal should last at least 250 milliseconds but can be as long as you want. The COMPENSATOR™ remembers the last value before the BASELINE contact opens.

Secondly, the control also automatically establishes a Baseline when the Start-up timer goes off. If each machine cycle includes starting the motor, an external BASELINE is not needed.

You need a BASELINE update for each machine cycle. The green Baseline LED is on DURING the update.

HOOKUP

Momentarily connect Terminal 3 to Terminal 5.

Check the Load Meter as the Baseline LED goes out. This is the value that the COMPENSATOR™ remembers. It should be the idle load of the machine.

MANUAL BASELINE UPDATE

During machine setup it is sometimes helpful to manually update the BASELINE. Do this by momentarily jumpering Terminal 3 to Terminal 5.

ANALOG OUTPUT AND FULL SCALE

The Analog Output is proportional to the power that is being sensed. This output is usually 0-1 milliamp but can also be 0-10 Volts or 4-20 milliamps. The output is hooked to a Percent Load Meter and the value of this signal can be calculated:

The Full Scale is proportional to the Voltage and Current Networks that are plugged into the Power Cell.

For 3 Phase Power PH-3 & PH-1000V

To calculate Full Scale Watts equivalent to full scale analog output:

$$\text{Watts} = (1.73) (\text{Voltage Network}) (\text{Current Network})$$

Example: 460 Volt Network
20 Amp Network
Watts = (1.73) (460) (20) = 15,916 Watts
Horsepower = Watts/746
= 21.3 Horsepower

For DC Power PH-1 & PH-1000DCV

To calculate Full Scale Watts equivalent to full scale analog output:

$$\text{Watts} = (\text{Voltage Network}) (\text{Current Network})$$

Example: 460 Volt Network
20 Amp Network
Watts = (460) (20) = 9,200 Watts
Horsepower = Watts/746
= 12.3 Horsepower

CHECK LIST

Power Cell Load Side Must Face Load (No Analog Output, Startup Light Doesn't Go Out)

Voltage samples must match phases. (No Sensitivity)

Voltage and Current Networks—Must be firmly inserted in CORRECT DIRECTION.

Remember—The Power Cell is sensing power rather than just current. Power is low for lightly loaded motors (because the power factor is low). The output signal increases linearly as the load increases.

ADJUSTMENTS

TRIP SET AND SET READ SWITCHES

The TRIP SET knobs set the power level at which the Load Control will trip. The SET READ switches show the trip point on the Percent Load Meter. Press the SET READ switch to read the set point.

For COMPENSATING Set Points, the set point is the level **ABOVE THE BASELINE** at which the Load Control will trip. With the power on but motor not running, the SET READ switch will show the **INCREASE** in load needed to trip. With the motor running, the SET READ switch shows the combined Baseline and Setting.

This means that the total Set Point for the COMPENSATING Controls will change as the Baseline or idle power changes during the day. But, the **INCREASE** always stays the same.

STARTUP TIMER

The STARTUP TIMER bypasses the control during motor startup to avoid false trips because of current inrush. For convenience, **THE TIMING BEGINS WHEN THE MOTOR STARTS**. The STARTUP LED stays lit until the Startup period is over.

Adjust the STARTUP time with the locking pot on the Load Control. Clockwise for more time. The Startup time should be:

- Long enough so that the load has stabilized. The Percent Load Meter should stabilize before the STARTUP LED goes out.
- Short enough so that the machine does not start a work cycle before the LED goes out.

ON-DELAY TIMERS

To avoid nuisance trips from short overloads, ON-DELAY TIMERS bypass the Control for the selected time. The relays won't trip until the time is exceeded. If the trip condition goes away before the time is up, the timer resets to zero.

- Always start with minimum ON-DELAY (full counterclockwise). If you are getting trips where you don't want them (as the tool is entering the workpiece for example) increase the ON-DELAY time.

PLM LOAD METER MOUNTING TEMPLATE

